



QUICK START GUIDE

Installation Parts




Radiator Installation




Pump Setup


Intel




AMD




Intel Back Plate Kit




AMD Back Plate Kit




Intel LGA1366/115X/17XX Setup




Intel LGA2066/ 2011 Setup




AMD AM4/ AM3/ FM2 Setup




AMD AM5 Setup



Fan/ Pump 3-Pin ARGB Cable Connection



Connection of PUMP header



Limits of Warranty:

- Warranty coverage does not include the following:
- A faulty product that leads to harm or damage to other products
 - Damage of product as a result of other product components
 - Incorrect method of operation or use of the product not for the intended use
 - Any form of alteration to the original product
 - Inability to install the product as a result of incompatibility with other components.

The Specifications are subject to change without notice.

Please consult our website for further information:
www.gelidsolutions.com

Disclaimer:

In no event shall GELID Solutions its directors or employees be liable for any indirect damages, incidental or consequential damages arising from any defect or error in this manual or product.

© Copyright 2022 All rights reserved by GELID Solutions Limited
All Brand names and Trademarks are the properties of their respective owners.