

Atomic Lite


Mini Tower Case

Save Money. Build Better.

User Manual
Manual del usuario
Bedienungsanleitung
Manuel d'utilisation

Manuale dell'utente
Podręcznik użytkownika
Руководство пользователя
Manual de utilizador

使用説明書/使用说明书
ユーザーズマニュアル
Нұсқаулары
Talimatlar



AeroCool
Cool


aerocool.io

Front I/O Cable Connection

Front I/O Connectors

(Please refer to the motherboard's manual for further instructions).

Note : Specifications may vary depending on your region. Contact your local retailer for more information.




Accessory Bag Contents

- | | | | |
|--|-----------------------|---|--|
| 1  x12 | SSD Screw
MB Screw | 2  x6 | PSU Screw
PCI Screw |
| 3  x6 | HDD Screw | 4  x2 | 3.5" HDD
Sliding Screw
For (5b) A |
| 5  x2 | MB Standoff | 6  x1 | Standoff Socket |
| 7  | x4 | Cable tie | |


How to Install Guide

(1) Install Motherboard




- | | |
|---|--|
| English
Install Motherboard | Русский
Установите материнскую плату |
| Español
Instalación de Placa madre | Português
Instalar a placa principal |
| Deutsche
Lüfter installieren | 繁体/简中
安裝主機板 / 安裝主机板 |
| Français
Installer carte mère | 日本語
マザーボードを取り付けます |
| Italiano
Installazione della scheda madre | Қазақ тілі
Аналық тақтаны орнатыңыз |
| Polski
Instalacja płyty głównej | Türkçe
Anakart yükleyin |

(2) Install PSU






- | | | | |
|--|---|---|---|
| English
Install PSU | Français
Installer unité d'alimentation | Русский
Установите блок питания | 日本語
PSUを取り付けます |
| Español
Instalación de Fuente | Italiano
Installazione della PSU | Português
Instalar a fonte de alimentação | Қазақ тілі
Қорек блогын орнатыңыз |
| Deutsche
Netzteil installieren | Polski
Instalacja zasilacza | 繁体/简中
安裝電源供應器 / 安裝电源供应器 | Türkçe
PSU yükleyin |

(3) Install Add-on Card






- | | | | |
|--|--|--|---|
| English
Install add-on Card | Français
Insérez la carte d'extension | Русский
Установите плату расширения | 日本語
ドオンカードを挿入します |
| Español
Inserte la tarjeta add-on | Italiano
Inserire la scheda aggiuntiva | Português
Insira a placa suplementar | Қазақ тілі
Кеңейту тақшасын салыңыз |
| Deutsche
Setzen Sie die Erweiterungskarte ei | Polski
Włóż dodatkową kartę | 繁体/简中
安裝擴充卡 / 安裝擴充卡 | Türkçe
Eklenli Yükleme Kartı |

(4a) Install 2.5" SSD x1





- | |
|--|
| English
Install 2.5" SSD |
| Español
Instalación de 2.5" SSD |
| Deutsche
2,5-Zoll-SSD installieren |
| Français
Installer SSD 2,5" |
| Italiano
Installare l'unità SSD 2,5" |
| Polski
Instalacja SSD 2,5" |

(5a) Install 3.5" HDD x1





- | |
|---|
| English
Install 3.5" HDD |
| Español
Instalación de 3.5" HDD |
| Deutsche
3,5-Zoll-Festplatte installieren |
| Français
Installer disque dur 3,5" |
| Italiano
Installare l'unità HDD 3,5" |
| Polski
Instalacja HDD 3,5" |

(4b) Install 2.5" SSD x1





(4c) Install 2.5" SSD x1 *install before (1)




- | |
|--|
| Русский
Установите 2.5" жесткий диск |
| Português
Instalar o SSD de 2,5" |
| 繁体/简中
安裝2.5" 硬碟 / 安裝2.5" 硬盘 |
| 日本語
2.5インチSSDを取り付けます |
| Қазақ тілі
2.5 «қатты дискіні» орнатыңыз |
| Türkçe
Yükleme 2.5 "SSD |

(5b) Install 3.5" HDD x1




- | |
|--|
| Русский
Установите 3.5" жесткий диск |
| Português
Instalar o HDD de 3,5" |
| 繁体/简中
安裝3.5" 硬碟 / 安裝3.5 "硬盘 |
| 日本語
3.5インチHDDを取り付けます |
| Қазақ тілі
3.5 «қатты дискіні» орнатыңыз |
| Türkçe
Yükleme 3.5 "HDD |

(6a) Install Front Fans




English Install Fan
Español Instalación de Ventilador
Deutsche Lüfter installieren
Français Installer ventilateur
Italiano Installazione della ventola
Polski Instalacja wentylatora

(6b) Install Top Fans x2




Русский Установите вентилятор
Português Instalar as ventoinhas

(6c) Install Rear Fan x1




繁體/簡中 安裝機箱風扇 / 安裝機箱風扇
日本語 ファンを取り付けます

(6d) Install PSU Fans x2




Қазақ тілі Желдеткіш орнатыңыз
Türkçe Fan yükleyin


(7a) Install Front Radiator




I/O Panel



(7b) Install Rear Radiator



English Install the radiator
Italiano Installare radiatore
繁體/簡中 安裝散熱排/安裝散熱排
Español Instalar radiador
Polski Zainstaluj chłodnicę
日本語 ラジエーターの取り付け
Deutsche Lüfter einbauen
Русский Установите радиатор
Қазақ тілі радиаторды орнатыңыз
Français Installer le radiateur
Português Instale o radiador
Türkçe radyatör takın



Press and hold LED Control Button for 3 sec to turn off LED. (For RGB Version Only)

Note : Specifications may vary depending on your region. Contact your local retailer for more information.