








Access Intercom Surface Angle Mount




1







2









3








4





5





If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).