


Thermalright

AXP-200 Muscle



AXP-200 Muscle

Assembly Package



x 4



x 1

4



x 7



x 4



x 5

4



x 5



x 5


4



x 1



x 1




x 1













8

Exploded View

Important! Before proceeding with installation, please check for the most up-to-date instructions at www.thermalright.com




Component

		
		
		
		
1 Heatsink Body ×1	2 Anchoring Mount ×1	3 Mounting Plate ×1
4 Screw Nut ×4	5 M3 L10 Screw ×5	6 M3 L6 Screw ×7
7 Intel Washer (small) ×4	8 AMD Washer (big) ×4	9 Thermal Paste ×1
10 TY-14013BW Fan×1	11 M3 L17 Screw ×5	12 M3 L28 Screw ×5

Installation Instructions:


Step 1:



Step 1 : Install the four screw pillars.

Take one M3L10 screw and put one washer for Intel around the screw pillar. Snap it through one of holes around CPU socket from bottom towards top. Cap the screw pillar with the screw nut included and then tighten up. Now repeat this installation for the other three screw pillars in a criss-cross pattern.



Step 2:



Step 2 : Place the Anchoing Mount on the Screw Nuts.

Use the four M3L6 screws to fix the Anchoing Mount on to the Screw Nuts


Step 3:



Step 3 : Applying Thermal Paste

Apply the Chill Factor thermal paste to the base of the Heatsink and the surface of the CPU evenly.


Step 4:



Step 4 : Mounting Plate Installation.

Place the Heatsink Body on top of the CPU. Make the Mounting Plate go through the Heatsink Body. Then use the two M3L6 screws to secure the Mounting Plate.


Step 5:



Step 5 : Fan Installation

Place the included TY-14013BW Fan onto the Heatsink Body. And then secure it by screwing on the four M3L17 Screws, through the fan's mounting hole.

Step 6:




Step 6 : Installation Completed













Plug in the fan connector to the CPU PWM Fan socket on the motherboard. Installation complete.

Exploded View

Important! Before proceeding with installation, please check for the most up-to-date instructions at www.thermalright.com




Component

		
		
		
		
1 Heatsink Body ×1	2 Anchoring Mount ×1	3 Mounting Plate ×1
4 Screw Nut ×4	5 M3 L10 Screw ×5	6 M3 L6 Screw ×7
7 Intel Washer (small) ×4	8 AMD Washer (big) ×4	9 Thermal Paste ×1
10 TY-14013BW Fan×1	11 M3 L17 Screw ×5	12 M3 L28 Screw ×5

Installation Instructions:


Step 1:



Step 1 : Install the four screw pillars.

Take one M3L10 screw and put one washer for AMD around the screw pillar. Snap it through one of holes around CPU socket from bottom towards top. Cap the screw pillar with the screw nut included and then tighten up. Now repeat this installation for the other three screw pillars in a criss-cross pattern.



Step 2:



Step 2 : Place the Anchoing Mount on the Screw Nuts.

Use the four M3L6 screws to fix the Anchoing Mount on to the Screw Nuts.


Step 3:



Step 3 : Applying Thermal Paste

Apply the Chill Factor thermal paste to the base of the Heatsink and the surface of the CPU evenly.


Step 4:



Step 4 : Mounting Plate Installation.

Place the Heatsink Body on top of the CPU. Make the Mounting Plate go through the Heatsink Body. Then use the two M3L6 screws to secure the Mounting Plate. (Screwdriver goes through holes on fins)


Step 5:



Step 5 : Fan Installation

Place the included TY-14013BW Fan onto the Heatsink Body. And then secure it by screwing on the four M3L17 Screws, through the fan's mounting hole.


Step 6:



Step 6 : Installation Completed


Plug in the fan connector to the CPU PWM Fan socket on the motherboard. Installation complete.

Step 1:



Step 1: Secure the fan by screwing on the four M3L28 Screws, through the fan's mounting holes.

Step 2:



Step 2: Installation Completed.
Plug in the fan connector to the CPU PWM Fan socket on the motherboard.

AXP-200 Muscle

Technical Spec

Heatsink Specifications:

Dimension: Length 149.99mm x Width 139.53mm x Height 59.65mm

Weight: 430g (Heatsink only)

Heatpipe: 6mm heatpipe*6 units

Fan Specification:

Dimension: L150mm x W140mm x H13mm


Weight: 90g

Fan speed: 700~1300RPM (PWM controlled)




Fan noise: 21.7~30.6 dBA MAX (Test distance 1.0M)

Airflow: 35.18~64.52CFM MAX

Connector: 4 Pin (PWM Fan connector)



AXP-200 Muscle





Thermalright -- Endorsed by Critics, Chosen by Experts



The Ultimate Cooling Solutions!



www.thermalright.com

TEL: +886-2-8663-6630

FAX: +886-2-8663-6645

EMAIL: sales@thermalright.com